


# Sewing Apron

keep your tools close by!




It's best to look thru the directions to familiarize yourself with all the steps. Check in the box  with each step you take to be sure you don't miss a step!




## Yardage

½ yard fabric


1 ½ yards of double folded bias tape,  
extra wide




1. Tape the 4 pages of pattern paper together at the connection dots, be sure not to overlap the paper. Cut the pattern out on the bold line.



2. Layout the fabric, folding the fabric in half to cut 2 fabric pieces, be sure the fabric is even and smooth before you start. Pin the pattern down close to the edges and cut right along the cutting line.




3. After cutting the fabric keep the pattern on and make little clips at notch points, this will help when matching up your fabric after the pattern is taken off.



4. With the right sides (pretty sides) of fabric together, pin to sew, matching edges and notches.



5. Then mark a 5/8 inch seam allowances around 3 sides, leaving the top open. Mark where you will pivot at lower edges.



6. Stitch around the 3 sides leaving the top open, be sure to reverse stitch at the beginning and ending of your stitches.




7. Clip the bottom corners for smoother corners when turning it right side out. Be sure not to clip the stitches or you'll have a hole.









**8.** Turn right side out, use a point turner (or a pencil) to get the corners sharp and all the way out. And then press really well.




**9.** From the top edge, measure down 3 inches, marking a line all the way across. This is where the bottom edge will fold up to.




**10.** Fold the lower edge to meet at the marked line, press. Then pin at sides, thru all thicknesses to prepare to sew.



**11.** Stitch edges thru all the thicknesses, be sure to reverse stitch at the top and bottom



**12.** Mark your pocket slots, you can create your own dimensions. We did ours as illustrated. Use a ruler and mark your lines before sewing.



**13.** Stitch at your marks, be sure to reverse stitch at the top and bottom of all the lines you stitch.





\*Double Folded Bias tape is used for your waistband and ties. (included in your kit)




**14.** Find the center of the waistband tape, (you do this by folding it in half ). Make a mark with a fabric marking tool.

Also, find the center of the apron top and mark.



**15.** Open up the waistband tape and “sandwich” the open end of the apron inside, matching up the centers



**16.** Pin the full length of the tape thru all the thicknesses. As illustrated.



**17.** Stitch the full length of the waistband tape, stitching close to the folded edge thru all the thicknesses



**18.** Press the marks off and clip all the threads and you're done!

